HAVIT



OWS902 OPEN-EAR WIRELESS HEADPHONES **USER MANUAL**

Product and accessories



Earbuds *2



Type-C Charging Cable *1



Charging Case*1




User manual *1



Certificate of quality *1

Description of product structure



- 1. Multifunction button(MFB)
- 2. Earbuds indication
- 3. Power LED indicator
- 4. Charging port

Wearing method

Gently insert the earbuds into the ear then adjust the appropriate comfort.



Basic function

01 Power on,Bluetooth connection

alternately, the other don't flash light.

-Follow the steps(Please confirm that your phone is built-in Bluetooth function.) 1. Power on

Open the charging case, the earbuds will turn on automatically. The earbuds enter the pairing mode automatically while the indicator of one earbud flashes blue light

2. Turn on Bluetooth function on your device and select "HAVIT OWS902" referring to your phone instructions. The indicator of earbuds turns off if the earbuds successfully paired.Pairing mode can just last 180 seconds.If you miss the pairing time.you need to restart the device and operate follow the procedural steps mentioned above.

*Note:

a). HAVIT OWS902 remembers previously connected devices. When turned on, earbuds attempts to reconnect to previously

connected devices.

b). HAVIT OWS902 will disconnect when deviate the working range of Bluetooth The earbuds will reconnect automatically if you come back to the range in 3 minutes.

02 Power off

Put the earbuds into the charging case and close the case, they will automatically shut

03 Answering incoming calls

Double tap the left or right MFB to answer incoming calls.

04 End the call

Double tap the left or right MFB to end the current call.

05 Decline incoming calls

Long press left or right MFB for 1s to reject a call.

06 Voice assistant

Triple tap the left or right MFB to activate voice assistant.

07 Music playing

- 1. Play/Pause:Double tap the left or right
- 2. Previous song:Long press the left MFB for
- 3. Next song:Long press the right MFB for 2s. *Note:If only one earbud works,long press left or right MFB for 2s to switch to next song.

08 Charging

-Case

Charge the case using the Type-C cable connected to a computer or wall charger. When the case is charging, the power LED indicator of the case flashes red, and turns steady red after fully charged.

09 Mono mode (Take out any earbuds as a unilateral wireless earbud.)

(Note: Single channel mode only needs to

remove one of earbuds from the charging box.if two earbuds are removed before connection, the earbud will be used in TWS mode by default, and the TWS connection will be automatically realized.)

- 1. Take out one earbud from charge case,the earbuds automatically turn on and reconnect to previous connected devices.
- 2. Switch from one earbud to the other earbud when playing music,taking out the other earbud from the charging case and these two earbuds will connected automatically.Both earbuds will play music automatically and then put the earbud which do not need anymore into the charging case and the switching process completes. (Note: Call mode is applicable.)
- 3. Please refer to the TWS mode for more functions.

10 Restore factory settings

If the earbuds can't pair frequently, please restore the factory settings. Press the MFB of the left and right earbud five times at the

same time, the red light of the earbuds flashes for 3 times and then shut down. Open the earbuds the earbuds will enter the pairing mode again, search the "HAVIT OWS902" Bluetooth pairing name with the mobile phone and connect again.

Specification

Bluetooth Version: V5.3 Bluetooth Working Range: 10M(Without obstacles) Earbuds Battery: 50mAh

Charging Case Battery: 400mAh Play Time: 6H(60% Vol.) Talk Time: 4H(60% Vol.) Case Charging Time: About 2H Speaker Size: Ф10*12 mm*2 Speaker Frequency: 20Hz~20kHz Input Voltage/Current: DC 5V/0.3A USB Port: Type-C

Warnings

6

- 1. Please follow the instruction to operate.
- 2. Please charge the earbuds with input

power below 5V/1A,in order to protect the

- 3. Please store or use the earbuds in a normal temperature environment.
- 4. Please do not use this product near the water. Do not immerse this product in any liquid or splash any liquid on this product.
- 5. Please keep the earbuds from heat source.such as radiators.hot air regulators, stoves, or other heat generating instruments. As it is not anti high tempera-
- 6. Don't jam the ports of the earbuds, such as charger port, LED port and microphone etc..
- 7. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the maximum level for a long time.
- 8. Whatever reasons damage the earbuds.please feel free to contact our after-sales staff in time rather than repair by yourself.Otherwise,you will accept without after-sales service.

8

5